

How To Use

Wet Core Bits

Attach the Alpha® Wet Core Bit onto your center water-feed polisher with a 5/8"-11 spindle.

Mark the location of holes that need to be drilled.

Use a template as a guide on the stone in order to avoid any mistakes during drilling process.

Clamp a piece of stone scrap under the stone being core drilled to prevent excessive chipping or “blowout” on the back side of the stone.

Proceed with drilling, pressing steadily until the wet core bit drills through the stone.

Refer to the owner’s manual of the tool for proper attachment and usage.